

CLASSIX[®] re-inking instructions

1. First, push down slightly on the top of the stamp and push the white locking buttons on either side of the stamp. This will allow the ink pad to slide out.



2. Second, carefully slide the ink pad out. The inked side of the pad will be on the bottom, take care not to get ink on your fingers.



3. Third, put a few drops of the same color ClassiX[®] refill ink onto the pad. For best results, allow the ink to saturate overnight.



1. First, push down slightly on the top of the stamp and push the black locking button on the front of the stamp. This will allow the ink pad to slide out.



2. Second, carefully slide the ink pad out. The inked side of the pad will be on the bottom, take care not to get ink on your fingers.



3. Third, put a few drops of the same color ClassiX[®] refill ink onto the pad. For best results, allow the ink to saturate overnight.

